

## **EMERGENCY LED DRIVER**

ITEM CODE:DRE30W94317



#### CAUTION:

- Before doing high-voltage insulation test, must remove the battery pack first and make sure there is no any contact between the battery pack and the led drivers
- During storage, the battey pack need 24 hours charge every 6 months

#### **FUNCTION: Indicator Light**

- AC Operation: Indicator light will stay ON
- Normal Emergency Operation: Indicator light slowly flashes ON / OFF
- Failure mode: Indicator light quickly flashes ON / OFF

#### General

Voltage	100~277Vac/347Vac,50/60Hz
Wattage	30W
Battery Type	Li-ion/Ni-MH
Input Current	100mA max.
Input Power Rating	7W max.
Output Voltage	20~50Vdc
Emergency Power	30W max.
Recharge Time	24Hrs
Discharge Time	≥1.5H

## **Specifications**

Ambient Temperature	Li-ion:32~122°F (0~50°C)	
Weight (lb.)	0.908 lbs(0.41kg)	
Surge Protection	Line-Neutral 3KV	

### Certification

cUL Listed	UL924 and tested to CSA C22.2 NO.141
RoHS Compliant	Yes

### **Additional Information**

Warranty 5 Year Limited

#### **Features**

- · High Output voltage
- Self-diagnostic circuitry performs testing automatically, reducing maintenance costs
- Auto-adjusting Class 2 25-50VDC output accommodates a wide range of LED designs
- Constant power design provides constant light output for 90 minutes
- Over temperature, over charge and discharge battery protection.
- · Over voltage and short circuit protection.
- · UL Listed for field installation

#### TEST SWITCH:

AC Operation:

Press test switch once, fixture will go in emergency mode for 30 seconds

AC Operation:

Press test switch twice within two seconds, fixture will go in emergency mode until battery is full discharged

Emergency Operation:
Press test switch once will turn off the emergency mode status. The LED fixture & status indicator light will go out at the same times.

# **SELF TEST**

# DIMENSIONS

•The emergency LED driver contains a control/monitor circuit which will perform a 30-second discharge test once a month and a fully discharge test once a year.

At this time, the unit simulate an AC power failure and automatically switch to emergency mode.

During routine testing, the unit will monitor the operation of the LED load, battery voltage, and emergency duration, if the unit detect any problems, the indicator will flash quickly.

#### Size of Li-ion battery's housing

Battery		Size(inch)						
Li-ion Battery		Length		Width		Height	Radius	
Picture	Power	L1	L2	W1	W2	/	R1	R2
11 12 12 10 R2 10	15W-20W	7.03"	6.43"	1.61"	0.91"	0.98"	0.1"	0.1"
	30W	7.03"	6.43"	1.61"	0.91"	1.73"	0.1"	0.1"
11- 12- 12- 11- 11- 12- 12- 12- 12- 12-	4W-8W	4.02"	3.58"	1.69"	0.67"	1.22"	0.08"	0.08"

#### Size of the EM driver's housing

Control Board	Size(inch)						
Control Board	Lei	ngth	Width	Height	Radius		
Picture	L1	L2	W1	/	R1		
$ \sqrt[L1]{12} $ $ \sqrt[R]{1} $	7.32"	7.07"	1.50"	1.0"	0.08"		







